



INSTALLATION TIPS

Concrete




①

Wood




②

Lathe & Plaster



③

Plasterboard



④

Wall to Floor (C2WF-15/30) Cable Installation

IMPORTANT: It is essential to check that the top ceiling fixings are strong enough to take the weight of the items being displayed, while allowing for the tension in the cables.

- 1) Select the upper height to which the cable is to begin. Affix base fitting (**A-B**) to wall using a suitable fixing for the type of wall:
 - for wooden walls use a wood screw.
 - for a cavity wall use a spring toggle bolt.
 - for a solid wall use a rawl plug and screw.
- 2) Attach the wall bracket (**A1-B1**) to the wall, at a respective distance from the top fixing (**A**), to form a regular triangle as shown in the diagram below.
- 3) Loosen the set screws on the wall bracket (**B1**) to slacken the front and back cables.
- 4) Using a plumb-line, descend from (**A1**), and affix fittings (**F-F1**) to floor using appropriate type of fixing.
- 5) Loosen the grub screws in fittings (**E-E1**), using the Allen key provided and slide fittings (**C-C1**), (**D-D1**) and (**E-E1**) up the cable.
- 6) Pull down the cable and cut off excess in-line with the decorative line around fittings (**F-F1**) (see below).
- 7) Tighten parts (**E-E1**) on the end of the cable.
- 8) Adjust the tension of the cable by screwing (**C-C1**) into (**F-F1**).
- 9) Tighten set screws on the wall bracket (**B1**) to affix the front and back cables in place.

NOTE: It is important to check the strength of the top fixing(s). Nova Display® takes no responsibility for incorrect installation. This responsibility rests with the installer.

Cables are not supplied with fixing screws.

***** DO NOT INSTALL INTO PLASTERBOARD (DRYWALL) CEILINGS OR WALLS IF YOUR APPLICATION INCLUDES GLASS SHELVING OR OTHER HEAVY ITEMS.**

